

INSTRUCTIONS FOR USE drawer cabinets

Products: drawer cabinets ZA 27x27D, ZB 36x36D, ZC 54x27D, ZD 36x27D, ZE 27x36D, ZG 54x36D, ZH 19x36D, ZK 45x36D, ZL 19x27D, ZN 27x19D, ZP 36x19D, ZR 45x19D, drawer cabinet accessories



To ensure safe and correct functioning of the products, it is absolutely essential to read these instructions and follow them. Observe the instructions and recommendations mentioned below. Non-observance of principles of safe use may result in injury or harm to the health of operating personnel, damage to the products or their parts, electrical shock, fire or death. Do not use the products under the influence of alcohol or drugs. Do not work with the products if you suffer from giddiness, weakness or faintness. Children must be supervised by adult persons.



Use:

Drawer cabinets are intended for production plants, assembly workshops, laboratories, test rooms, repair shops, training workshops and similar plants. They are suitable for medium to heavy work of a metalworking nature and all places requiring storage or work with heavy objects (tools, instruments, devices) or for special use, such as archiving of documents, mineralogy, etc.

Before immobile drawer cabinets are used, they must be set into the horizontal position and anchored. When using drawer cabinets, always strictly observe their maximum permissible loading and space layout. It is forbidden to transfer a mobile drawer cabinet with the upper part loaded on an inclined plane, or place additional heavy loads on the objects stored on it. Further, it is forbidden to sit or stand on the drawer cabinets or transport persons by means of them. During transport, never leave them unattended; after stopping, secure them against movement. Pull out the drawers only if the drawer cabinets cannot start moving spontaneously. When extending drawers provided with a lock against self-extension, unlock the latch first. Heavier objects are preferably to be placed in the lower parts to prevent the cabinet from toppling over. Immobile products must always be moved empty and only by carrying. Use handling devices to move them. For anchoring methods and other specific information, see the online virtual consultancy POLAK SMART FURNITURE at www.smfu.eu. Weights of individual products and capacities of bearing areas are indicated in the current catalogue of workshop furniture, which can be found at www.polakcz.cz. Do not overload any of the products or their parts or use them other than for the intended purpose. The total load must not exceed the maximum permissible load of the weakest element of the given product.

It is forbidden to apply greater force on the drawers and doors than is necessary to open and close them. If the objects placed inside hinder easy closing, rearrange them, never using force. If the drawers are not provided with interlocking, always extend one drawer only. Only lock the cabinet if all the drawers are pushed in properly.

The drawer cabinets are not dustproof; therefore, it is necessary to consider their location in plants with increased content of dust particles in the air (joinery workshops, etc.).

For all of the products, only place and use accessories recommended and approved by the manufacturer. It is forbidden to modify the design of the drawer cabinets or accessories in any way. Use them in conformity with the safety instructions only. Electric strips can only be connected by qualified personnel. Provide for initial inspection of the electrical equipment, and then for regular inspections according to the legal regulations in force.

If objects are stored which could damage the surface or individual parts owing to their nature, the cabinets can be protected by additional accessories, such as by rubber linings. We recommend that you choose a suitable type of product with regard to its use and operating load in coordination with the seller. Forcible handling may result, for instance, in permanent deformation of metal parts, breakage of a key or a malfunction of extensions.

The drawer cabinets have been designed for use in interiors, in a dry environment with a stable temperature and adequate humidity. Products with the BUK-MASIV and MULTIPLEX worktop must be located in environments with a relative air humidity of 55%, tolerance +/- 5% (during production of the bonded worktop, wood is dried to 8-10% moisture, which corresponds to a relative air humidity of 55%.). Using them outside the given range of air humidity causes deformation, which results in the loss of the guarantee. Do not use the products in direct contact with water or in a humid environment. Do not perform manufacturing works which could directly damage their surface or structure unless they are specifically intended for these purposes. Do not expose them to heat sources so that they cannot heat up excessively.

For instructions for setting, repairs and replacement of parts, see www.smfu.eu

Maintenance:

Maintenance involves the application of lubricant to extensions and other friction surfaces, cleaning the surface of impurities with a wet cloth and subsequent drying. For cleaning, use common cleaning agents for household use, intended for plastic and coated metal surfaces of furniture. Do not clean surfaces of metal parts mechanically; do not use abrasive powder agents, agents based on organic solvents, salts, acids or lyes, which can impair the coated surface.

Product disposal:



The products and packaging materials contain parts which can affect the environment after disposal. At the end of their service life, the created waste must be disposed of in conformity with the legal regulations in force. The product consists of parts which can be sorted and recycled separately.

Guarantee conditions:

The operator is obliged to follow the instructions contained in the user manual. Their non-observance is considered a breach of the guarantee conditions. The guarantee does not cover parts worn due to normal operation.

Manufacturer:





